ENGR 21: Computer Engineering Fundamentals

Lecture 5 Tuesday, September 16, 2025

Test #1 of 6 on Thu 9/18 Based on Weeks 1-2, incl. HW 1-2

In-class, 8:30 to 8:55 Paper exam; no computers / electronic devices Bring a calculator & pen/pencil

Accuracy & Precision for the accelerometer on the Circuit Playground Bluefruit

The on-board accelerometer (first, try interactively!)


Make sure you first run the line

from adafruit_circuitplayground import cp



• X, Y and Z

What are the units?



$$|\vec{\alpha}| = \sqrt{\alpha_x^2 + \alpha_y^2 + \alpha_z^2}$$

What happens if you tilt the board?

>>> cp.acceleration acceleration(x=0.0383047, y=-0.114914, z=9.69109)
>>> cp.acceleration.z is acceleration.x
$$9.69109$$
 9.69109

○ A https://emadmasroor.github.io/E21-F25/Resources/ ENGR 21 Fall 2025 Resources Resources External Guides and Tutorials Instructor's Circuit Playground Guide for E21 Links and Code Snippets Lec 1.1, Tue Sep 2 Lec 2.1, Tue Sep 9

Lec 3.1, Tue Sep 16

Accelerometer

copy code from here into code.py!

```
. . .
# Number of readings
N = 10
# Create a list that will store the readings
readings_z = [0] * N
readings = [0] * N
# Time delay between measurements
for j in range(N): # Number of seconds to run
    accel_z = cp.acceleration.z
    accel = magnitude(cp.acceleration.x, cp.acceleration.y,cp.acceleration.z)
    print((accel_z,accel))
    readings[i] = accel
    readings_z[j] = accel_z
    time.sleep(delay) # delay of 1 second
avg_reading = sum(readings)/len(readings)
avg_reading_z = sum(readings_z)/len(readings_z)
print("After ",N," readings, the acceleration is ",avg_reading," m/s^2")
print("With standard deviation ", std(readings))
print("After ",N," readings, the z-acceleration is ",avg_reading_z," m/s^2")
print("With standard deviation ",std(readings_z))
```

Quantifying accuracy & precision for accelerometer

Accuracy

Precision

ENGR 21 Fall 2025

Saving Data in Files On the Circuit Playground Bluefruit

ENGR 21 Fall 2025

Resources

- Resources
 - External Guides and Tutorials
 - Instructor's Circuit Playground Guide for E21
 - Links and Code Snippets
 - Lec 1.1. Tue Sep 2
 - Lec 2.1, Tue Sep 9
 - Lec 2.2, Thu Sep 11
 - Lec 3.1, Tue Sep 16

Storing Data on the Circuit Playground Bluefruit

It is possible to store data on the board, even when disconnected from your PC and powered with battery

Task: Download boot.py and save it to CIRCUITPY.

After boot.py is on your board, you will be able to switch between computer com save

1. Read-only mode file


2. Writable mode Circuit Python co

Either your computer can save files to your board, or CircuitPython can save files to your board.

not both!!

To switch between modes:

- Slide switch
- Eject CIRCUITPY from OS
- Press reset button



Read-only (by CircuitPython)

Writable (by CircuitPython)

NGR 21

○ △ https://emadmasroor.github.io/E21-F25/Resources/ ENGR 21 Fall 2025 Resources Resources External Guides and Tutorials Instructor's Circuit Playground Guide for E21 Links and Code Snippets Lec 1.1, Tue Sep 2 Lec 2.2, Thu Sep 11 Lec 3.1, Tue Sep 16

Storing Data on the Circuit Playground Bluefruit

Download Reaction times game from Resources page

after

saving to code.py, slide switch ->

```
Reaction times game
 from adafruit_circuitplayground import cp
 import time
 import random
 # Choose the number of data points to collect
 N = 5
 # Create a list to collect data points
 data = [0] * N
 # Print some information
 print("Welcome to the reaction time game.")
 print(f"We will collect {N} samples.")
 print("Press button A when an LED lights up.")
 # Open file for writing
 f = open("/reaction_times.txt","a")
 for j in range(N):
     # Turn off all LEDs
     cp.pixels.fill((0, 0, 0))
     # Wait for a random time between 1 and 5 seconds
     random delay = random.uniform(1, 5)
     time.sleep(random delay)
```

```
Has extra lines composed to

HW that save data an

board.

# Open the file

f = open("/reaction_times.txt", "a")

# Write to file

f.write(f"{reaction_time:.4f}\n")

f.flush()

Variable

# Close the f

f.close()
```

Activity: Modify Accelerometer to collect data

Goal: Save 30 seconds of accelerometer data when switched on with battery power, into a text file on board the CIRCUITPY.

Start from the code from <u>Reaction Time Game</u> and <u>Accelerometer</u>

(both from Resources Page)

ENGR 21 Fall 2025 10